#### 8 Bluetooth Kinetic Switch

HBKS01/W A one-gang Switch



### Product Description

HBKS01 series is a one-button Bluetooth kinetic switch (self-powered), with a lifespan of 100,000 repeated presses, and available in black and white. It requires no batteries or wiring, offering the flexibility to be freely placed or adhered to according to the needs. Moreover, HBKS01 series features "short press" and "long press" button combinations, allowing to achieve dimming control, scene recall, and quit manual mode through the **Koolmesh**<sup>®</sup> app. All simple device setup and commissioning can be done via the **Koolmesh**<sup>®</sup> app.



## App Features

#### Single Short Press

- 1. On/Off control
- 2. Scene recall
- 3. Quit manual mode

#### Press And Hold

- 1. Dimming control
- 2. Colour tuning (Warm to Cool White)

## Hardware Features


- Self powered
- Without battery
- S Without wiring
- Freely placeable
- 💁 Waterproof (no electric shock)
- . Key indicator light



# Technical Specifications & Dimensions

Bluetooth Transceiver	
Operation frequency	2.4 GHz - 2.483 GHz
Transmission power	0 dBm
Range (Typical indoor)	10~30m
Protocol	₿ Bluetooth®


Overview		
Power supply	Self-powered (kinetic energy)	
Channels	l (one-gang)	
Mounting	Adhesive pad option is being supplied in the box, for use on smooth surfaces only	
Lifetime	100,000 actuation (switching cycles)	
Housing material	PC	
Switch pressing force	≦700g (reference only, individual variations exist)	
Dimensions	86 x 86 x15mm	
Operation temperature	Ta: -10°C ~ +40°C	



### Optional Accessories For Switch Bezel


The Switch Bezel is an accessory for Hytronik kinetic switches in Basalt Grey. It enhances accessibility, especially for those with impaired vision or limited hand mobility. Compliant with the UK's Part M regulations, it ensures safe and easy usage for everyone.

HAKS01/W, HAKS01/B (size:mm)



For the installation of a single switch


HAKS02/W, HAKS02/B (size:mm)



For the installation of double switches


# Method 1: Adhesive Mounting

\* If the wall surface is clean and smooth, directly peel off the double-sided adhesive tape and stick the switch to the wall.




## Method 2: Installation with Original Switch Box

\* If prefer to install it on the original switch box, use screws for installation.







# Dimming Interface Notes

Detailed Push switch configurations can be set on Koolmesh app.

Switch Function	Action	Descriptions
Push switch	Short press (<1 second) * Short press has to be longer than 0.1s, or it will be invalid.	- Turn on/off - Recall a scene - Turn on only - Quit manual mode - Turn off only - Do nothing
	Long press (≥1 second)	- Dimming - Colour tuning (Warm to Cool White) - Do nothing

# Additional Information / Documents

- 1.To learn more about detailed product features/functions, please refer to www.hytronik.com/download ->knowledge ->Introduction of App Scenes and Product Functions
- Regarding precautions for Bluetooth product installation and operation, please kindly refer to www.hytronik.com/download ->knowledge -> Bluetooth Products - Precautions for Product Installation and Operation
- 3. Data sheet is subject to change without notice. Please always refer to the most recent release on www.hytronik.com/products/bluetooth technology ->Bluetooth Accessories
- 4. Regarding Hytronik standard guarantee policy, please refer to www.hytronik.com/download ->knowledge ->Hytronik Standard Guarantee Policy