Installation and Instruction Manual



Wieland 4-Pole Terminal Base Quick Connection Box (QCB)

QCB01

1.Description

Wireland 4-pole terminal base quick connection box for non-dimmable control applications, with 8 luminaire outlets and 1 sensor outlet. Freely switch between 1-channel and 2-channel control. Rating of system 16A, rating of each output 10A.


2. Key Features


- . Non-dimmable control applications
- . 8 luminaire outlets + 1 extra sensor outlet for sensor connection
- . Luminaire outlet: GST type 4-pole terminal base (L', N, E, Em)
- . Sensor outlet: GST type 8-pole terminal base (L, N, E, L1', L2', P1, P2)
- . Black housing and white housing available to choose from
- Freely switch between 1-channel (1 x 8) & 2-channel (2 x 4) control
- Tamper-proof structure design
- . Rating of system: Max 16A. Rating of each output: Max 10A
- · Flame-retardant material for safety protection

3. Your Benefits

- · Five types of installation methods meets different project needs
- · Reduce labour hours and labour cost significantly
- . Simple and intuitive wiring connections
- . Improved safety level during wiring operations
- . Clear and clean wiring makes it easy for future maintenance
- . Can be supplied with pre-wired cables

4. Dimensions (mm)






Subject to change without notice.



Attention: When the input power supplies are from two different phases, the voltage between the two L terminal could be as high as 415V.

5. Input & Output Terminal Function



Wire Range: 0.75 - 4.0mm2 (max. 2 x 2.5mm2)



Luminaire outlet




Sensor outlet

Edition: 3 May. 2023

Page 1/4

By removing this pre-installed jumper wire, the 8 outlets are then divided into two separate channels. This QCB01 becomes a 2-channel box with 2 x 4 luminaire outlet. The two channels will be controlled separately (Channel 1 is controlled by Switched L1, and Channel 2 is controlled by Switched L2).



6.Installation methods

Surface Mount

It can work with $4 \times M6$ screws to fix onto both walls and ceilings.



Channel Nut Mount


It can work with channel nuts to fasten into the back.



Marco Tray Mount

It can work with Marco clips steel wire cables tray system.

BESA/Junction Box Connection It can be connected with BESA/junction box.



Page 2/4








Subject to change without notice. Edition: 3 May. 2023

7. Wiring Diagram

Factory default setting with a pre-installed jumper wire One-channel (1x8) switching control




Note: 1. For two-channel (2x4) switching control please remove the jumper wire.


2. Do not wire across phases.

Wiring & Emergency Test

Local lighting switch and local emergency test switch



Using Local lighting switch for power interruption




___ jumper wire

Note: 1. A local lighting switch may still be used when there is a central emergency test switch or when a circuit breaker is used to interrupt the power. 2. Do not wire across phases

Emergency test using central switch

Subject to change without notice.



Note: 1. A local lighting switch may still be used when there is a central emergency test switch.

2. Do not wire across phases.

Edition: 3 May. 2023

Ver. AO

Page 3/4

8. Ceiling Rose

Description

Ceiling rose QCCR01 can be used when there is a need to take power and dimming signal from a conduit box. The installation-friendly design comes with a very spacious termination space for really easy wirings.

Key Features


- . Can be freely placed or fixed with BESA/junction box
- Taking power from BESA/junction box
- . 6-pole GST type connector (L, E, N, Em, Dim+, Dim-)
- · Allowing fast connection with quick connection box
- . 15mm depth big cabling space
- . 48-68mm pitch for conduit mounting
- Nominal current max.16A
- · Flame-retardant material for safety protection




*QCCR01 is supplied with white color housing by default. Black color housing can be supplied upon request

Input & Output Terminal Function

Mechanical Structure & Dimensions



Secure QCB01 with BESA/Junction box



Connection to QCB01



9. Additional Information / Documents

Regarding Hytronik standard guarantee policy, please refer to www.hytronik.com/download ->knowledge ->Hytronik Standard Guarantee Policy

Subject to change without notice. Edition: 3 May. 2023 Ver. AO Page 4/4