Constant Current, Self-Test

# HYTRONK B CE SELV EL-T

# **Product Description**

HBEMO3 is a combined LED driver & emergency control gear with Bluetooth module built inside. HBEMO3 is ideal for lighting manufacturers with new plastic luminaire design. It can conduct monthly or annually testing automatically and user can get email notification as soon as fault is detected. Meanwhile, simple device setup and commissioning can be done via

Koolmesh app.

# App Features

 $\mathcal G$  Quick setup mode & advanced setup mode

Floorplan feature to simplify project planning

Web app/platform for dedicated project management

Koolmesh Pro iPad version for on-site configuration

Grouping luminaires via mesh network

Scenes

Dusk/Dawn photocell (Twilight function)

Push switch configuration

Compatible with EnOcean BLE switches

Internet-of-Things (IoT) featured

Device firmware update over-the-air (OTA)

Device social relations check

Bulk commissioning (copy and paste settings)

Offline commissioning

P Different permission levels via authority management

Network sharing via QR code or keycode

Remote control via gateway support HBGW01

(🖒 Interoperability with Hytronik Bluetooth product portfolio

Continuous development in progress...



### Hardware Features

Photocell Advance<sup>TM</sup>

Insulated terminal cover with cord restraint

Active PFC design

Over-temperature Protection

Short-circuit Protection

Overload Protection

5 5-year warranty, designed for long lifetime up to 50,000 hours

# **Emergency Features**

Multi emergency wattage: 2W/3W/4W

Emergency working mode:

- Normal emergency mode

- Rest mode

- Inhibit mode

- Extended emergency mode


Monthly/Annually Automatic Testing

with report generation

Battery status check via Koolmesh app

Automatic email notification when fault is detected

Retrievable usage data and report history



# **Technical Specifications**

| Bluetooth Transceiver  |                                  |
|------------------------|----------------------------------|
| Operation frequency    | 2.4 GHz - 2.483 GHz              |
| Transmission power     | 4 dBm                            |
| Range (Typical indoor) | 10~30m                           |
| Protocol               | <b>₿Bluetooth</b> ® 5.0 SIG Mesh |

# LED Current Selection


|     | ••••                            | 1050mA |
|-----|---------------------------------|--------|
| •   | $\bullet \bullet \bullet \circ$ | 900mA  |
| C   |                                 | 700mA  |
| بال | $\bullet$ 000                   | 500mA  |
| ١   | 0000                            | 350mA  |
|     | 1 2 3 4                         |        |


# Emergency Power Selection

| 4W | 0   | •  |
|----|-----|----|
| 3W | •0  | Ϊ́ |
| 2W | 00  |    |
|    | 1 2 | ŏ  |

| Model No.  | HBEM03  |  |  |  |  |
|--|---|--|--|--|--|
| Mains voltage  | 220~240VAC 50/60Hz  |  |  |  |  |
| Mains current  | 0.24~0.22A  |  |  |  |  |
| Max. output wattage  | 40W   |  |  |  |  |
| Output wattage /   | 1050mA 900mA 700mA 500mA 350mA  |  |  |  |  |
| LED current /  | 24-38V 24-45V 24-48V 24-50V 24-50V 25-40W 16-40.5W 16-33.5W 12-25W 8-17.5W  |  |  |  |  |
| voltage<br>Max. Efficiency   | 88%   |  |  |  |  |
| Output voltage(U-out Max.)   | 60V   |  |  |  |  |
| Power factor   | >0.9  |  |  |  |  |
| Operation temperature  | 0~+50°C   |  |  |  |  |
| Storage temperature  | -10~+45°C   |  |  |  |  |
| Battery pack   | BPC83, BPC84  |  |  |  |  |
| Battery Type (LiFePO4) / Charge current /<br>Discharge current / Max. load /<br>Discharge hour | BPC83&84: 6.4V/3.4AH, 0-500mA, 0.4A, 2W@24-50VDC, 3H<br>6.4V/3.4AH, 0-500mA, 0.56A, 3W@24-50VDC, 3H<br>6.4V/3.4AH, 0-500mA, 0.8A, 4W@24-50VDC, 3H |  |  |  |  |
| Charge period  | 24h   |  |  |  |  |
| Max. case temp.  | 85℃   |  |  |  |  |
| Over-heat protection   | Over-heat protection with auto-reset.   |  |  |  |  |
|  | Short circuit protection  |  |  |  |  |
| Battery abnormal protection  | Reverse connection protection   |  |  |  |  |
| ·  | Deep discharge  |  |  |  |  |
| EMC standard   | EN55015, EN61547, EN61000-3-2, EN61000-3-3  |  |  |  |  |
| Safety standard  | EN61347-1, EN61347-2-7, EN62034, IEC62133   |  |  |  |  |
| Certifications   | CE , EMC, ROHS  |  |  |  |  |
| IP grade   | IP20  |  |  |  |  |

# Mechanical Structure & Dimensions





# Wire Preparation



Solid or Stranded wire type 0.75 -  $1.5 \, \text{mm}^2$  To make or release the wire from the terminal, use a screwdriver to push down the button.


#### Circuit Breaker Information


| Automatic circuit breaker type | B16A | BIOA | B13A | B20A |
|--------------------------------|------|------|------|------|
| НВЕМО3                         | 40   | 25   | 32   | 50   |


Calculation uses typical values from ABB series S200 as a reference. E.g. Maximum amount = 16/(Pn/230). We recommend to use no more than 60% of the data as the actual max. number of drivers in real application. Actual values may differ due to used circuit breaker types and installation environment.


Subject to change without notice. Edition: 07 Nov. 2024 Ver. AO Page 3/6


# Performance Characteristics













# **Dimming Characteristics**



Subject to change without notice. Edition: 07 Nov. 2024 Ver. AO Page 4/6

# Dimming Profile



| Dimming range | Dimming technique |  |  |
|---------------|-------------------|--|--|
| 0%            | OFF               |  |  |
| 1-100%        | PWM               |  |  |

#### Normal Mode

It is the mode in which mains supply is available, with the battery charged or charging. In this mode, HBEMO3 is a dimmable emergency driver, with ability to create scenes and controllable by motion sensor, Push switch and app.

#### **Emergency Mode**

It is the mode in which mains supply has failed and whilst the control gear is powered by the battery until deep discharge point. In this mode, HBEMO3 is unable to be controlled by motion sensor, Push switch and app. However, some emergency parameterscan still be configured via the app, such as time scheduled for self-test, duration for extended emergency mode etc.

#### Rest Mode

It is the mode in which the luminaire is intentionally off whilst the control gear is powered by the battery. To enter this mode, the prerequisite is that there is no mains supply. In this mode, the luminaire will be turned off automatically and HBEMO3 is powered by the battery. If the luminaire is forced to turn on in this mode, HBEMO3 will then be adjusted to emergency mode. When mains supply is recovered, HBEMO3 will return to normal mode.

#### Inhibit Mode

It is the mode in which HBEM03 is powered from the mains but prevented from going into emergency mode in the event of mains failure. Please enter this mode only in special applications whereby emergency function is not needed, such as when electrician needs to cut off power supply when doing examination and maintenance work for HBEM03.

# Extended Emergency Mode

It is the mode in which the control gear continues to operate the lamp in the same way as in emergency mode for the programmed prolong time after the restoration of the mains supply. When this mode is enabled, HBEM03 will remain in emergency mode even when mains supply is recovered. In this mode, the user has to set the time extended for emergency mode; when the time extended elapses, HBEM03 will then return to normal mode.

### Self test

HBEMO3 carries out routine test on emergency lighting based on pre-programmed time via the app or after receiving manual commands from the app. During the self test process, tests for load connections (such as open circuit, short-circuit) and battery connections (such as open circuit, short-circuit, polarity reversal etc. will be carried out.

Subject to change without notice. Edition: 07 Nov. 2024 Ver. AO Page 5/6

# **LED Diagnostics**

| Indicator Colour                        | Status             | Meaning  |  |  |
|---|--------------------|--|--|--|
| GREEN SOLID                             | Device OK          | All OK, AC power is present. Battery is connected & charging   |  |  |
| GREEN FAST FLASH<br>(0.1s ON, 0.1s OFF) | Monthly test       | AC power is present. Monthly test in progress  |  |  |
| GREEN SLOW FLASH (1s ON, 1s OFF)        | Annual test        | AC power is present. Annual test in progress   |  |  |
| RED SOLID                               | LED fault          | LED is open circuit, short circuit or has otherwise failed in some way, Fault can indicate the live status or the result of a test   |  |  |
| RED FLASH<br>(1s ON, 1s OFF)            | Battery fault      | Battery failure (Battery failed the duration or functional test, battery appears to be defective, battery has incorrect voltage). Fault can indicate the live status or the result of a test |  |  |
| RED /GREEN OFF                          | No power available | AC power is lost, unit in emergency mode   |  |  |

# **Battery Pack Options**

| Package<br>code | Picture  | Spec.                   | Size (mm) | Duration                      | Recharge<br>Time | Accessories                                       |
|-----------------|--|-------------------------|-----------|-------------------------------|------------------|---|
| BPC83           | E CONTRACTOR AND ADDRESS OF THE CONTRACTOR A | LiFePO4,<br>6.4V, 3.4Ah | 110x55x27 | 3h @3VV<br>3h @2VV<br>3h @4VV | 24h              | Battery bracket,<br>LED indicator,<br>Test switch |
| BPC84           | Service const  | LiFePO4,<br>6.4V, 3.4Ah | 170x30x27 | 3h @3VV<br>3h @2VV<br>3h @4VV | 24h              | Battery bracket,<br>LED indicator,<br>Test switch |

Please kindly note that the optimal storage temperature should be 22°C to 28°C.

The relative humidity (RH) for battery storage should be 45% to 85%.

Keep the battery wires unconnected if the battery is intended to be stored for more than 3 months.

The maximum battery cycles under 55°C should not exceed 80 times.

Please kindly charge battery for 24 hours before using.

Do not short-circuit the battery pack.

# Additional Information / Documents

- 1. Regarding precautions for Bluetooth product installation and operation, please kindly refer to www.hytronik.com/download/knowledge ->Bluetooth Products - Precautions for Product Installation and Operation
- 2. Regarding precautions for LED driver installation and operation, please kindly refer to www.hytronik.com/download/knowledge ->LED Drivers - Precautions for Product Installation and Operation
- 3. Regarding precautions and usage for LiFePO4 battery, please kindly refer to www.hytronik.com/download/knowledge ->LiFePO4 Battery - Precautions and Usage
- 4. Data sheet is subject to change without notice. Please always refer to the most recent release on www.hytronik.com/products/bluetooth technology ->Bluetooth Emergency Driver/Inverter
- 5. Regarding Hytronik standard guarantee policy, please refer to www.hytronik.com/download/knowledge ->Hytronik Standard Guarantee Policy

Edition: 07 Nov. 2024